

Installation and user guide

240UHM-XXX H/C

| | | |
|------------------|----------|----------------|
| Update Record | Revision | 1.1.0 |
| | Date | November. 2010 |

CLAMP ON ULTRASONIC BTU METER

Description

Ultrasonic BTU meter (240UHM Series) clamp onto the outside of pipes without contacting the internal liquid. The ultrasonic measuring technology has many advantages, such as low-cost and fast installation, no moving parts to maintain or replace, excellent dynamic range, and nearly all kinds fluid compatibility. It is available for pipe size DN20--DN600, the cable length between calculator and flow meter is no more than 10 meters, default value is 1.5 meters. The length of Temperature sensor pairs is no more than 40 meters, default value is 1.5 meters.

Specifications

| Performance specifications | |
|----------------------------------|---|
| Flow range | (0~±5 m/s) |
| Accuracy | ±1.0% of measured value (for 0.7~3.5 m/s) |
| Repeatability | 0.4% |
| Pipe size | 20mm to 600mm |
| Fluid | Water |
| Pipe material | Carbon steel, stainless steel, PVC, etc. |
| Function specifications | |
| Outputs | Analog output: 4~20mA |
| Network Interface | Network Protocol: BACnet, Modbus, M-bus |
| | Baud Rate: 2400bps |
| Power supply | 24VDC, 1A(max) |
| Keypad | 16 (4×4) key with tactile action |
| Display | 40 character, 2 line (20×2) lattice alphanumeric, backlit LCD |
| Temperature | Transmitter: -10°C~50°C |
| | Transducer: 0°C~80°C |
| Humidity | Up to 99% RH, non-condensing |
| Physical specifications | |
| Transmitter | PC/ABS, IP65 |
| Transducer | Encapsulated design, IP68 |
| double-shielded transducer cable | Standard: 9m |
| Weight | Transmitter: approximately 0.7kg |
| | Transducer: approximately 0.4kg |

Features

- High precision measurement
- Low starting flow-rate
- Installation can be vertical or horizontal
- The M-bus, BACnet and Modbus output port have realized the functions of data transmission and centralized control
- Both cooling and heating are available (measurement can be in the mode of cooling or heating)

*****About commissioning and installation for the Flow Meter, please refer following files.

Thank you for choosing the 240 UHM Ultrasonic Flowmeter with DCTSI CMOS and low-voltage wide-pulse sending technology.

This instruction manual contains important information. Please read carefully before the operation of the flowmeter.

This instruction manual will introduce how to use the flowmeter step-by-step, including product component, installation, wiring, quick setup etc. to make it easier to operate.

Understanding more about the menu settings can fulfill your higher requirements with the flowmeters' powerful function option and output function.



Warning

May cause injury.









Attention

May damage the flow meter.

Some of the instructions may different to the flowmeters you purchased, depending on configuration requirements at the time of purchasing or the change of the product design and upgrade requirement. There is no indication in the instructions, please refer to the version number.

Product Component


Inspection should be made before installing the Flowmeter. Check to see if the spare parts are in accordance with the packing list. Make sure that there is no damage to the enclosure due to a loose screw or loose wire, or other damage that may have occurred during transportation. Any questions, please contact your representative as soon as possible.

| Transmitter | Transducers |
|---|--|
|  |  |
| Accessories | Documents |
| <div>   </div> <div>  </div> <div> <div>Pipe Straps</div> <div>Coupling compound</div> <div>Install accessory</div> </div> | <div>  </div> <div> <ol style="list-style-type: none"> 1. Instruction Manual 2. Packing List 3. Position drawing </div> |


Transmitter Installation and Connect

1.1. Inspection prior to Transmitter Installation

You will find a “Position Drawing” in the packing. Please use it as a template in the place that you are going to install the Flowmeter. Then drill 4 installing holes at the screws position shown on the drawing with the 5.5mm drill.



Take out the enclosed screws and plastic bushings. Insert the plastic bushings into the installing holes. Brackets will be installed at the bottom of the flowmeter. Put the flowmeter to the position and screw it in.



Attention

When installing please ensure the front cover is secure and will not fall open.

1.2. Wire Connecting

1.2.1. Power supply

Customers should pay special attention to specify the desired power supply when wiring.

Factory standard power supply is 24VDC


To ensure the transmitter can work normally, please pay attention to the followings when wiring:

Ensure that power connections are made in accordance with the specifications shown on the transmitter.

1.2.2. Transmitter Wiring


Once the electronics enclosure has been installed, the Flowmeter wiring can be connected.

Open the case, you will find the transmitter interfaces labels from left to right as follows:



1.2.3. Calculator Wiring

Power supply of the calculator is DC-24V, red cable is positive polarity while black cable is negative polarity. Wiring error will damage the calculator.



1.2.4. Lengthened Cable Method

Standard cable length of sensor is 9 meters; it can be lengthened to be 300 meters according to the actual need for fluid measurement.




Warning

Wire with power off. The flow meter must be reliable grounding before installation.


1.2.5. Installation Instructions

Temperature sensor pairs installation

Temperature sensors for heat meter of DN 20~600mm are installed on the supply and return pipe with the sleeve. Drilling a hole of $\phi 20$ on the pipe and weld the straight-way vertically on the pipe. Then install the sleeve on the straight-way, insert the temperature sensor into the sleeve, make sure the sleeve is inserted to the bottom, then mount the rubber sealing ring and lock nut in order and screw them tightly to make sure the sensor can't be pulled out easily.



1.2.6.Display



LCD (6A1044A)

Display information

Continuously press the key for more than 1s; it will switch displaying with current information ▲, monthly information ▲▲ and other information ▲▲▲. If the key is pressed for less than 1s, the internal information of the current value, monthly value and other information will be alternately displayed.

Display unit

The energy unit displayed is J or W•h and decimal system and the flow-rate unit is m³. Any other needs with the measuring unit shall be added in the order.

Other instructions on display and keyboard

- 1 "Monthly Reading Date" displays as "PD=XX", in which XX is the end date of current month's energy cumulating; The factory default value is 31, it means the current month's cumulated energy will be conserved at this 0 minute 0 o'clock of the 31st date of each month and the system will begin to record the next month's energy.
- 2 Totally 18 pieces history monthly recordings can be displayed. If less than 18 pieces, only the existed recordings will be displayed.
- 3 "Accumulative Working Time" displays the unit "h", the unit is hour;
- 4 "Software and hardware edition No." displays as "VEr.X.X X.X". The first X.X is the software edition code; following it is the hardware edition code.
- 5 "Leaving-factory serial number" is the meter's physical address number, which shall be the same with the one in the external label. "Leaving-factory serial number" is a unique number set by the factory.
- 6 "Battery voltage" displays "VCC= X.XX", the unit is not displayed and the default unit is V; When the battery's voltage capacity is lower than 2.9±0.1V, it will display "BAT" in non-battery voltage state, so as to suggest the battery voltage is low.
- 7 Error message

If there are unsolved errors in "Failure record", the end date will display "00-00-00", which indicates that the failures are not solved. If there are less than 4 in failure record, then only the existing failure record will be displayed.

| Error message | Explanations |
|---------------|---|
| IN—CLOSE | Temp. sensor of water supply is in short circuit condition |
| IN—OPEN | Temp. sensor of water supply is in open circuit condition |
| OU—CLOSE | Temp. sensor of return water is in short circuit condition |
| OU—OPEN | Temp. sensor of return water is in open circuit condition |
| FL-OPEN | Flow sensor failure. (There is air existed or the sensor is not in the water or it is reversely installed, pay attention to the water inflow direction) |
| COD=XXXX | There is an error in malfunction record. "XXXX" is the error code |

1.3. Powering on











As soon as the Flowmeter is switched on, the self-diagnosis program will start to run. If any error is detected, an error code will display on the screen (Refer - Error Diagnoses). After that self-diagnosis, the system will run automatically according to the last input parameters.

If the installation is accomplished when system is switched on, gain adjustment can be monitored in Window M01. After S1, S2, S3, S4 are displayed on the upper left corner of the screen, the system will activate the normal measurement condition automatically. It is indicated by code “*R” on the upper left corner of the screen.

If it is the first use or install on a new site, the customer need to input the new installation site parameters. The system will default to the last window settings and automatically display them at next power on.

1.4. Keypad Functions





Follow these guidelines when using the Flowmeter keypad (Refer to Keypad Figure):








-  ~  And  To input numbers.
-  Backspace or delete characters to the left.
-  And  Return to the last menu or to open the next menu. Acts as “+” and “-” functions when entering numbers.
-  Select a menu. Press this key first, input two menu numbers and then enter the selected menu. For example, to input a pipe outside diameter, press  keys, where “11” is the window ID to display the parameter for pipe outside diameter.






1.5. Keypad Operation

The flow meter adopts the window software design to consolidate or subdivide all of the parameters entered, the instrument setup and measurement result displays into more than 100 independent windows. The operator can input parameters, modify settings or display measurement results by “visiting” a specific window. These windows are arranged by 2-digit serial numbers (including “+” sign) from 00~99, then to +0, +1, etc. Each window serial number, or so-called window ID code, has a defined meaning. For example, Window M11 indicates the parameter input for pipe outside diameter, while Window M25 indicates the mounting spacing between the transducers, etc. (Refer – Windows Display Explanations).





The keypad shortcut to visit a specific window is to press the  key at any time, then input the 2-digit window ID code. For example, to input or check the pipe outside diameter, just press the  keys for window ID code 11.

Another method to visit a particular window is to press  and  keys to scroll the screen. For example, if the current window ID code is M02, press  key to enter Window M01, press the  button again to enter Window M00; then, press the  key to back Window M01, and press the  key again to enter Window M02.










Windows are separated into three types: (1) Data Type, such as M11, M12; (2) Option Type, such as M14; (3) Pure Display Type, such as M01, M00.






You can check the corresponding parameters by visiting the Data Type Windows. If you want to modify the parameters, input the digits and press  or press  first, input the digits then press  again to confirm.










Example1: To enter a pipe outside diameter of 219.234, the procedure is as follows:

Press  keys to enter Window M11 (the numerical value displayed currently is a previous value). Now press  key. The symbol “>” and the



flashing cursor are displayed at the left end of the second line on the Screen. Then input the parameters; or do not press the  key, directly enter        .



You can check the selected option by visiting Option Type Windows. If you want to modify it, you must press  first, the symbol ">" and the flashing cursor are displayed at the left of the Screen. Operator can use the  and  to scroll the screen and get the required value then press  to confirm; or enter the corresponding value option directly and press  to confirm.

For example, if the pipe material is not "Stainless Steel", Press    to enter Window M14, press  to modify the options. Select the "1. Stainless Steel" option by pressing  and , then press  to confirm the selection; It is possible to press  key to change the selection and wait until "1.Stainless Steel" is displayed on the second line of the screen, then press  to confirm.

Pipe Material [14
>1. Stainless Steel



Attention

Generally, press  key first if operator wants to enter "modify" status. If the "modify" is still not possible even after pressing the  key, it means that system is locked by a password. To "Unlock" it, select "Unlock" in Window M47 and enter the original password.

1.6. Flowmeter Window Descriptions

The Flowmeter has the unique feature of windows processing for all operations. These windows are assigned as follows:

- 00~09 Flow Totalizer Display: to display flow rate, positive total, negative total, net total, velocity, date & time, present operation and flow results today, etc.
- 10~29 Initial Parameter Setup: to enter pipe outside diameter, pipe wall thickness, fluid type, transducer type, transducer mounting method and spacing, etc.
- 30~38 Flow Units Options: to select the flow unit such as cubic meter, liter or other units, can turn totalizers on/off and reset totalizers, etc.
- 40~49 Setup options: Scaling factor, system lock (Window M47), etc.
- 55~89 Input and output setup: date and time, ESN, communication baud rate setting, etc.
- 90~94 Diagnoses: Signal strength and signal quality (Window M90), TOM/TOS*100 (Window M91), flow sound velocity (Window M92), total time and delta time (Window M93), Reynolds number and factor (Window M94), etc.
- +0~+5 Appendix: power on/off time, total working hours, on/off times and a single-accuracy function calculator.










Attention

The other windows are for hardware adjustment which reserved by the manufacturer.

2. Pipe Parameter Entry Shortcuts






For example, measuring the diameter of DN200, measuring medium is water, Pipe Material is carbon steel, No Liner, can be operated as follows:

Step1. Pipe outside diameter:

Press    keys to enter Window M11, and enter the pipe outside diameter of   , and then press the  key to confirm.










Step2. Pipe wall thickness

Press the    key to enter Window M12, and enter the pipe wall thickness of , and press the  key to confirm.









Step3. Pipe Material

Press the    keys to enter Window M14, press the  key, press the  or  key to select Pipe Material, and press the  key to confirm.










Step4. Transducers type

(Transmitter support different types of transducers) Press the    to enter Window M23, press the  or  key to select transducer type, and press the  key to confirm.




Transducer Type [23
0. Standard

Step5. Transducer mounting methods

Press the    key to enter Window M24, press the  key, press the  or  key to select transducer-mounting method, and press the  key to confirm.






Step6. Adjust Transducer spacing

Press the    key to enter Window M25, accurately install the transducer according to the displayed transducer mounting spacing and the selected mounting method (Refer to Installing the Transducers in this chapter).



Step7. Display measurement result

Press the    keys to enter Window M01 to display measurement result. (Base on the actual measurement)



3.Measurement Site Selection

When selecting a measurement site, it is important to select an area where the fluid flow profile is fully developed to guarantee a highly accurate measurement. Use the following guidelines to select a proper installation site:

Choose a section of pipe that is always full of liquid, such as a vertical pipe with flow in the upward direction or a full horizontal pipe.

Ensure enough straight pipe length at least equal to the figure shown below for the upstream and downstream transducers installation.



Ensure that the pipe surface temperature at the measuring point is within the transducer temperature limits.

Consider the inside condition of the pipe carefully. If possible, select a section of pipe where the inside is free of excessive corrosion or scaling.

4. Transducer Installation

4.1 Installing the transducers

Before installing the transducers, clean the pipe surface where the transducers are to be mounted. Remove any rust, scale or loose paint and make a smooth surface. Choose a section of sound conducting pipe for installing the transducers. Apply a wide band of sonic coupling compound down the center of the face of each transducer as well as on the pipe surface, ensure there are no air bubbles between the transducers and the pipe wall, and then attach the transducers to the pipe with the straps provided and tighten them securely.

Note:

The two transducers should be mounted at the pipe's centerline on horizontal pipes.

Make sure that the transducer mounting direction is parallel with the flow.

During the installation, there should be no air bubbles or particles between the transducer and the pipe wall. On horizontal pipes, the transducers should be mounted in the 3 o'clock and 9 o'clock positions of the pipe section in order to avoid any air bubbles inside the top portion of the pipe. (Refer to Transducer Mounting). If the transducers cannot be mounted horizontally symmetrically due to limitation of the local installation conditions, it may be necessary to mount the transducers at a location where there is a guaranteed full pipe condition (the pipe is always full of liquid).

4.1.1 Transducer spacing

After entering the required parameters, the spacing between the ENDS of the two transducers is considered as the standard transducer spacing (Refer to Top View on transducer mounting methods). Check the data displayed in Window M25 and space the transducers accordingly.

4.1.2 Transducer Mounting Methods

Four transducer mounting methods are available. They are respectively: V method, Z method and N method. The V method is primarily used on small diameter pipes DN25~400mm, (1~16"). The Z method is used in applications where the V method cannot work due to poor signal or no signal detected. In addition, the Z method generally works better on larger diameter pipes (over DN300mm, 12") or cast iron pipes.

4.1.3 V Method

The V method is considered as the standard method. It usually gives a more accurate reading and is used on pipe diameters ranging from 25mm to 400mm (1~16") approximately. Also, it is convenient to use, but still requires proper installation of the transducers, contact on the pipe at the pipe's centerline and equal spacing on either side of the centerline.



4.1.4 Z Method

The signal transmitted in a Z method installation has less attenuation than a signal transmitted with the V method when the pipes are too large, there are some suspended solid in the fluid, or the scaling and liner are too thick . This is because the Z method utilizes a directly transmitted (rather than reflected) signal which transverses the

liquid only once.

The Z method is able to measure on pipe diameters ranging from 100mm to 600mm (4" ~24") approximately. Therefore, we recommend the Z method for pipe diameters over 300mm (12").



4.2 Transducer Mounting Inspection

Check to see if the transducer is installed properly and if there is an accurate and strong enough ultrasonic signal to ensure proper operation and high reliability of the transducer. It can be confirmed by checking the detected signal strength, total transit time, delta time as well as transit time ratio.

The “mounting” condition directly influences the flow value accuracy and system long-time running reliability. In most instances, only apply a wide band of sonic coupling compound lengthwise on the face of the transducer and stick it to the outside pipe wall to get good measurement results. However, the following inspections still need to be carried out in order to ensure the high reliability of the measurement and long-term operation of the instrument.

4.2.1 Signal Strength

Signal strength (displayed in Window M90) indicates a detected strength of the signal both from upstream and downstream directions. The relevant signal strength is indicated by numbers from 00.0~99.9. 00.0 represents no signal detected while 99.9 represents maximum signal strength.

Normally, the stronger the signal strength detected, the longer the operation of the instrument reliably, as well as the more stable the measurement value obtained.

Adjust the transducer to the best position and check to ensure that enough sonic coupling compound is applied adequately during installation in order to obtain the maximum signal strength.

System normally requires signal strength over 60.0, which is detected from both upstream and downstream directions. If the signal strength detected is too low, the transducer installation position and the transducer mounting spacing should be re-adjusted and the pipe should be re-inspected. If necessary, change the mounting method to be Z method.

4.2.2 Signal Quality (Q value)

Q value is short for Signal Quality (displayed in Window M90). It indicates the level of the signal detected. Q value is indicated by numbers from 00~99. 00 represents the minimum signal detected while 99 represent the maximum.

Normally, the transducer position should be adjusted repeatedly and coupling compound application should be checked frequently until the signal quality detected is as strong as possible.

4.2.3 Total Time and Delta Time

“Total Time and Delta Time”, which displays in Window M93, indicates the condition of the installation. The measurement calculations in the Flowmeter are based upon these two parameters. Therefore, when “Delta Time” fluctuates widely, the flow and velocities fluctuate accordingly, this means that the signal quality detected is too poor. It may be the resulted of poor pipe-installation conditions, inadequate transducer installation or incorrect parameter input.

Generally, “Delta Time” fluctuation should be less than $\pm 20\%$. Only when the pipe diameter is too small or velocity is too low can the fluctuation be wider.

4.2.4 Transit Time Ratio

Transit Time Ratio indicates if the transducer mounting spacing is accurate. The normal transit time ratio should be 100 ± 3 if the installation is proper. Check it in Window M91.

Attention

If the transit time ratio is over 100 ± 3 , it is necessary to check:



- (1) If the parameters (pipe outside diameter, wall thickness, pipe material, liner, etc.) have been entered correctly,
 - (2) If the transducer mounting spacing is accordance with the display in Window M25,
 - (3) If the transducer is mounted at the pipe's centerline on the same diameter,
 - (4) If the scale is too thick or the pipe mounting is distorted in shape, etc.
-




Warnings

- (1) Pipe parameters entered must be accurate; otherwise the Flowmeter will not work properly.
 - (2) During the installation, apply enough coupling compounds in order to stick the transducers onto the pipe wall. While checking the signal strength and Q value, move the transducers DCTowly around the mounting site until the strongest signal and maximum Q value can be obtained. Make sure that the larger the pipe diameter, the more the transducers should be moved.
 - (3) Check to be sure the mounting spacing is accordance with the display in Window M25 and the transducer is mounted at the pipe's centerline on the same diameter.
 - (4) Pay special attention to those pipes that formed by steel rolls (pipe with seams), since such pipe is always irregular. If the signal strength is always displayed as 0.00, that means there is no signal detected. Thus, it is necessary to check that the parameters (including all the pipe parameters) have been entered accurately. Check to be sure the transducer mounting method has been selected properly, the pipe is not worn-out, and the liner is not too thick. Make sure there is indeed fluid in the pipe or the transducer is not too close to a valve or elbow, and there are not too many air bubbles in the fluid, etc. With the exception of these reasons, if there is still no signal detected, the measurement site has to be changed.
 - (5) Make sure that the Flowmeter is able to run properly with high reliability. The stronger the signal strength displayed, the higher the Q value reached. The longer the Flowmeter runs accurately, the higher the reliability of the flow rates displayed. If there is interference from ambient electromagnetic waves or the signal detected is too poor, the flow value displayed is not reliable; consequently, the capability for reliable operation is reduced.
 - (6) After the installation is complete, power on the instrument and check the result accordingly.
-

5 . Operating Instructions

5.1 System Normal Identification

Press the  keys. If the letter “*R” displays on the screen, it indicates system normal.

If the letter “E” is displayed, it indicates that the current loop output is over ranged by 100%. This refers to the settings in Window M57. Enter a larger value in Window M57, and the letter “E” will disappear. It can be ignored if no current loop output is used.

If the letter “Q” is displayed, it indicates that the frequency output is over ranged by 120%, and this refers to the settings in Window M69. Increase the input value in Window M69, and the letter “Q” will disappear. It can be ignored if no frequency output is used.

If the letter “H” is displayed, it indicates that the ultrasonic signal detected is poor. For more information, please refer to “Error Diagnoses”.

If the letter “G” is displayed, it indicates that system is adjusting the signal gain prior to the measurement. Also, it means system normal. Only when the adjustment takes too long without stopping, can system be identified as abnormal.

Letter “I” indicates no signal is being detected. Check the transducer wiring connections are correct, the transducers are installed firmly, etc.

Letter “J” indicates a hardware defect exists. Normally, such defect is temporary; it could be eliminated by system reboot (power off and restart).

Letter “F” indicates hardware defect.


For further information, please refer to “Error Diagnoses”.

5.2 Zero Set Calibration

Once zero flow occurs, a zero point may indicate on each measuring instrument, but the displayed measuring value is not equal to “0”, this value indicates “Zero”. To any measuring instrument, the smaller the “Zero” is, the better the quality is. Conversely, if the Zero is too big, that indicates the quality of the instrument is poor.

If the zero set point is not at true zero flow, a measurement difference may occur. The smaller the physical measurement capacity is, the larger the measurement difference from the zero point will exist. Only when zero point reduced to a definite degree, as compared with the physical measurement capacity, can the measuring difference from zero point be ignored.

For an ultrasonic Flowmeter, the measurement difference from zero point cannot be ignored at low flow. It is necessary to perform a static zero set calibration to improve low flow measurement accuracy.

Press Window M42 to set the Zero, press  first, and then wait the readings displayed at the lower right corner reducing to be “0”. If this is carried out with flow, the flow will be displayed as “0”, M43 can help to restore settings.

5.3 Scale Factor







Scale factor refers to the ratio between “actual value” and “reading value”. For example, when the measurand is 2.00, and it is indicated as 1.98 on the instrument, the scale factor reading is 2/1.98. This means that the best scale factor constant is 1.

However, it is difficult to keep the scale factor as “1” on the instrument especially in batch productions. The difference is called “consistency”.

During operation, there still exists possible difference in pipe parameters, etc. The “scale factor” may be necessary when used on different pipes. Thus, scale factor calibration is specially designed for calibrating the differences that result from application on different pipes. The scale factor entered must be one that results from actual calibration. The scale factor can be input in Window M45.

5.4 System Lock (Unlock)

System lock is readable but uneditable to prevent operation error due to unauthorized tampering by unauthorized personnel.

Press the  keys, if displays “Unlock” on the screen, then press the  key, enter a 1~4 numerically long password, and then press the  key to confirm.

Unlock it by using the selected password only. Press  , if displays “lock” on the screen press the  key and enter the correct password, then press  to confirm.







Keep the password in mind or recorded in a safe place, otherwise the instrument cannot be used.

5.5 4~20mA Current Loop Verification

Processing a current loop output exceeding an accuracy of 0.1%, the flowmeter is programmable and configurable with multiple output modes such as flow rate or fluid velocity. Select in Window M55. For details, please refer to “Windows Display Explanations”.

In Window M56, enter a 4mA flow rate or fluid velocity value. Enter the 20mA flow rate or fluid velocity value in Window M57. For example, if the flow range in a specific pipe is 0~1000m³/h, enter 0 in Window M56 and 1000 in Window M57.

Calibrating and testing the current loop is performed in Window M58. Complete the steps as follows:

Press  , move  or  to display “0mA”, “4mA”, “8mA”, “12mA”, “16mA”, “20mA” readings, connect an ammeter to test the current loop output and calculate the difference. Calibrate it if the difference is within tolerance. If the difference is without tolerance, refer to the “Analog Output Calibration” to calibrate the current loop.

Check the present current loop output in Window M59 as it changes along with change in flow.

5.6 Recover the Factory Default

Press  to Window M37, press  keys to recover the factory default.






5.7 4~20mA Analog Output Calibration






NOTE:

Each flowmeter has been calibrated strictly before leaving factory. It is unnecessary to carry through this step except when the current value (detected while calibrating the current loop) displayed in Window M58 is not identical with the actual output current value.

The hardware detect window must be activated prior to calibration the Analog Output. The procedure is as follows:

Press  enter password “4213068”, then press  to activate the detect menu. With no effect to next power on, this window will close automatically as soon as the power is turned off.

Press  to calibrate the current loop 4mA output. Use an ammeter to measure the current loop output current. At the same time, press  or  to adjust the displayed numbers. Watch the ammeter until it reads 4.00. Stop at this point, the 4mA has been calibrated.

Then, press  to calibrate the current loop 20mA output. The method is the same as 4mA calibration.

The results are automatically saved in EEPROM and won't lose when power off.

5.8 ESN

We provide the Flowmeter with a unique electronic serial number to identify each Flowmeter for the convenience of the manufacturer and customers. The ESN is able to be viewed in Window M61.



Attention

Other Operation refers to “6.2 Windows Display Explanations”.

Windows Display Explanations

6.1. Windows Display Codes

| Flow Totalizer Display | |
|-------------------------|------------------------------|
| 00 | Flow Rate/Net Totalizer |
| 01 | Flow Rate/Velocit |
| 02 | Flow Rate/POS Totalizer |
| 03 | Flow Rate/NEG Totalizer |
| 04 | Date Time/Flow Rate |
| 08 | System Error Codes |
| 09 | Net Flow Today |
| Initial Parameter setup | |
| 11 | Pipe Outer Diameter |
| 12 | Pipe Wall Thickness |
| 14 | Pipe Material |
| 23 | Transducer Type |
| 24 | Transducer Mounting Method |
| 25 | Transducer Spacing |
| 26 | Parameters Setups |
| 27 | Current Cross-sectional Area |
| 28 | Holding with Poor Sig |
| 29 | Empty Pipe Setup |
| Flow Units Options | |
| 31 | Flow Rate Units |
| 32 | Totalizer Units |
| 33 | Totalizer Multiplier |
| 34 | Net Totalizer |
| 35 | Pos Totalizer |
| 36 | NEG Totalizer |
| 37 | Totalizer Reset |
| 38 | Manual Totalizer |
| Setup Options | |
| 40 | Damping |
| 41 | Low Flow Cutoff Value |
| 42 | Set Static Zero |
| 43 | Reset Zero |

| 44 | Manual Zero Point |
|------------------------|----------------------------------|
| 45 | Scale Factor |
| 46 | Network identifying address code |
| 47 | System Lock |
| Input and output setup | |
| 55 | CL Mode Select |
| 56 | CL 4mA Output Value |
| 57 | CL 20mA Output Value |
| 58 | CL Check |
| 59 | CL Current Output |
| 60 | Date and Time |
| 61 | ESN |
| 62 | Serial Port Parameter |
| 68 | Low FO Flow Rate |
| 69 | High FO Flow Rate |
| 70 | LCD Backlit Option |
| 72 | Working Timer |
| 77 | Beeper Setup |
| 82 | Date Totalizer |
| 83 | Automatic Correction |
| Diagnoses | |
| 90 | Signal Strength and Quality |
| 91 | TOM/TOS*100 |
| 92 | Fluid Sound Velocity |
| 93 | Total Time and Delta |
| 94 | Reynolds Number and Factor |
| Appendix | |
| +0 | Power ON/OFF time |
| +1 | Total Working Hours |
| +2 | Last Power Off Time |
| +3 | Last Flow Rate |
| +4 | ON/OFF Times |
| -0 | Hardware Adjusting Entry |

NOTE: The other menu features are retained by manufacturers and the windows in gray background are optional functions.

6.2. Display explanation

While reading this section, please compare it with the instrument in order to improve your understanding.



Flow Rate / Net Totalizer

Display flow rate and net totalizer.

If the net totalizer has been turned off (refer to M34), the net totalizer value displayed is the total prior to its turn off.



Flow Rate / Velocity

Display flow rate and velocity.



Flow Rate / Positive Totalizer

Display flow rate and positive totalizer.

Select the positive totalizer units in Window M31.

If the positive totalizer has been turned off, the positive totalizer value displayed is the total prior to its turn off.



Flow Rate / Negative Totalizer

Display flow rate and negative totalizer.

Select the negative totalizer value in Window M31.

If the negative totalizer has been turned off (refer to M36), the value displayed is the total prior to turn off.



Date Time / Flow Rate

Display the current date time and flow rate.

The time setting method can be found in Window M60.



System Error Codes

Display the working condition and the system error codes. More than one error code can occur at the same time.

The explanations of error codes and detailed resolution methods can be found in "Error Diagnoses".



Net Flow Today

Display net total flow today.





Pipe Outer Diameter

Enter the pipe outside diameter or enter the pipe circumference in Window M10. The pipe outside diameter must range from 10mm to 6000mm.

Note: Enter either pipe outside diameter or pipe circumference.





Pipe Wall Thickness

Enter the pipe wall thickness.



Pipe Material

Enter pipe material. The following options are available (by ,  buttons or numerical keys):

| | |
|-----------------|--------------------|
| 0. Carbon Steel | 1. Stainless Steel |
| 2. PVC | |



Transducer Mounting

Four mounting methods are available:

0. V
1. Z use



Transducer Spacing


The operator must mount the transducer according to the transducer spacing displayed (be sure that the transducer spacing must be measured precisely during installation). The system will display the data automatically after the pipe parameter had been entered.




Initial Parameter Setups and Save

Load and save the parameters. 18 different sets of setup conditions/groups are available to load and save by three methods (i.e.-you can load and save 18 different applications):

0. Entry to Save
1. Entry to Load
2. To Browse

Select "Entry to Save", press . An ID code and the original parameters are displayed in the window. Press UP or DOWN ARROW to move the ID code, then



press the  key again to save the current parameter in the current ID room.

When selecting “Entry to Load”, press ENT, and the system will read and calculate the parameters automatically and display the transducer mounting spacing in Window M25.



Display the current cross-sectional area

Cross-sectional Area
31415.9 mm²



Holding with Poor Sig

Select “Yes” to hold last good flow signal displayed if the Flowmeter experiences a poor signal condition. This function will allow continued data calculation without interruption.



Empty Pipe Setup

This parameter is used to overcome the possible problems that usually show up when the pipe being measured is empty. Since signals can be transmitted through the pipe wall, the flow meter may still read a flow while measuring an empty pipe. To prevent this from happening, you can specify a value. When the signal quality falls below this value, the measurement stops automatically. If the flow meter is already able to stop measuring when the pipe is empty, a value in the range of 30 to 40 should also be entered in this window to ensure no measurement when the pipe is empty.



* It should be understood that the instrument is NOT designed to function correctly on an empty pipe.



Flow Rate Units Options

The following flow rate units are available:

0. Cubic Meters (m³)
1. Liters (l)
2. USA Gallons (GAL)
3. Imperial Gallons (Imp gal)
4. Million Gallons (mg)
5. Cubic Feet (cf)
6. USA Barrels (US bbl)
7. Imperial Barrels (Imp bbl)
8. Oil Barrels (Oil bbl)

The following time units are available:/Day /Hour /Min /Sec, Factory default is Cubic Meters/hour





Totalizer Units Options

Select totalizer units. The available unit options are as same as those found in Window M31. The user can select units as their requirement. Factory default is Cubic Meters.



Totalizer Multiplier Options

The totalizer multiplier acts as the function to increase the totalizer indicating range. Meanwhile, the totalizer multiplier can be applied to the positive totalizer, negative totalizer and net totalizer at the same time. The following options are available:

0. X0.001(1E-3)
1. X0.01
2. X0.1
3. X1
4. X10
5. X100
6. X1000
7. X10000(1E+4)

Factory default factor is x1



ON/OFF Net Totalizer

On/off Net Totalizer. "ON" indicates the totalizer is turned on, while "OFF" indicates it is turned off. When it is turned off, the net totalizer displays in Window M00 will not change. Factory default is "ON".



ON/OFF POS Totalizer

On/off POS Totalizer. "ON" indicates the Flowmeter starts to totalize the value. When it is turned off, the positive totalizer displays in Window M02 will not change. Factory default is "ON".






ON/OFF NGE Totalizer

On /off NGE Totalizer. "On" indicates the totalizer is turned on. When it is turned off, the negative totalizer displays in Window M03 will not change.

Factory default is "ON".



Totalizer Reset

Totalizer reset; all parameters are reset. Press ; press  or  arrow to select "YES" or "NO".



After “YES” is selected, the following options are available:

- None: No reset;
- All: Reset all totalizers;
- NET Totalizer Reset;
- POS Totalizer Reset;
- NEG Totalizer Reset.

If the user wants to delete all the already set parameters and set back to the factory default, press



in this window and then the flow meter will reset to be the factory default automatically.





Attention

This operation will delete the entire user's data and reset as the factory default. Please consider carefully before taking this operation.



Manual Totalizer

The manual totalizer is a separate totalizer. Press  to start, and press  to stop it. It is used for flow measurement and calculation.

Manual Totalizer [38
Press ENT When Ready



Damping Factor

The damping factor ranges from 0~999 seconds. 0 indicates no damping; 999 indicates the maximum damping.

The damping function will stabilize the flow display.

Its principle is the same as that in a single-section RC filter. The damping factor value corresponds to the circuit time constant.

Usually a damping factor of 3 to 10 is recommended in applications.

Damping [40
10 sec



Low Flow Cutoff Value

Low Flow Cutoff is used to make the system display as “0” value at lower and smaller flows to avoid any invalid totalizing. For example, if the cutoff value is set as 0.03, system will take all the measured flow values below ± 0.03 as “0”. Usually 0.03 is recommended in most applications.

Low Flow Cutoff Val.
0.01 m/s

Menu 4 2

Set Static State Zero

When fluid is in the static state, the displayed value is called “Zero Point”. When “Zero Point” is not at zero in the Flowmeter, the difference is going to be added into the actual flow values and measurement differences will occur in the Flowmeter.

Set zero must be carried out after the transducers are installed and the flow inside the pipe is in the absolute static state (no liquid movement in the pipe). Thus, the “Zero Point” resulting from different pipe mounting locations and parameters can be eliminated. The measuring accuracy at low flow is enhanced by doing this and flow offset is eliminated.

Press **ENT**, wait for the processing instructions at the right corner bottom to reach 0.

Performing Set zero with existing flow may cause the flow to be displayed as “0”. If so, it can be recovered via Window M43.

Set Zero [42
Press ENT to go

Menu 4 3

Reset Zero

Select “YES”; reset “Zero Point” which was set by the user.

Reset Zero [43
NO

Menu 4 4

Manual Zero Point

This method is not commonly used. It is only suitable for experienced operators to set zero under conditions when it is not preferable to use other methods. Enter the value manually to add to the measured value to obtain the actual value. For example:

Actual measured value = 250 m³/H

Value Deviation = -10 m³/H

Flowmeter Display = 240 m³/H

Normally, set the value as “0”.

Manual Zero Point [44
0 m³/h

Menu 4 5

Scale Factor

The scale factor is used to modify the measurement results. The user can enter a numerical value other than “1” according to the actual calibration results.

Scale Factor [45
1

Menu 4 6

Network IDN

Input system identifying code, these numbers can be selected from 0~65535 except that 13 (0DH ENTER), 10 (0AH Newline), 42 (2AH *) and 38 (26H&) are reserved. System IDN is used to

Network IDN [46
88

identify the flowmeter to a network.

Menu 4 7

System Lock

Lock the instrument.

Once the system is locked, any modification to the system is prohibited, but the parameter is readable. "Unlock" using your designated password. The password is composed of 1 to 4 numbers.

System Lock [47]
* * * * Unlocked * * * *


Menu 5 5

Current Loop Mode Select

Select the current loop mode. The following options are available:

- | | |
|-----------------------|---|
| 0. 4-20mA Output Mode | set up the 4-20mA output to be flow rate mode |
| 1. 4-20mA vs. Vel | set up the 4-20mA output to be flow velocity mode |
| 2. 4-20mA vs. Energy | set up the 4-20mA output to be energy mode |

Other different current output characteristics are displayed in below figures. The user can select one of them according to his actual requirements.



In two graphs shown above, flow F_{4mA} indicates the value that the user entered in Window M57; and flow F_{20mA} indicates the value that the user entered in Window M58. In the 4-20mA modes, F_{4mA} and F_{20mA} can be selected as a positive or negative flow value as long as the two values are not the same.

In 4-20mA flow rate mode, the output current is indicated as velocity. In 4-20mA energy mode, the output is indicated as energy.

Menu 5 6

CL 4mA Output Value

Set the CL output value according to the flow value at 4mA. The flow unit's options are the same as those in Window M31. Once "4-20mA vs. Vel." is selected in Window M56, the unit should be set as m/s.

CL 4 mA Output Value
0 m3/h

Menu 5 7

20mA Output Value

Set the CL output value according to the flow value at 20mA. the flow unit is the same as that found in Window M31. Once "4-20mA vs. Vel." is selected in Window M57, the unit should be set as m/s.

CL 20mA Output Value
14400 m3/h

Menu **5** **8**

CL Check Verification

Check if the current loop has been calibrated before leaving the factory. Press **ENT** to start, press **UP** to display 0mA, 4mA, 8mA, 12mA, 16mA, 20mA, and at the same time, check with an ammeter to measure the current loop output current and calculate the differences to see if it is under the permitted tolerance. If not, refer to the “Analog Output Calibration” to calibrate.

CL Checkup [58
Press ENT When Ready

Menu **5** **9**

CL Current Output

Display CL current output. The display of 10.0000mA indicates that CL current output value is 10.0000mA.

If the difference between displaying value and CL output value is too large, the current loop then needs to be re-calibrated accordingly.

CL Current Output [59
15.661 mA

Menu **6** **0**

Date and Time Settings

Date and time modifications are made in this window. The format for setting time setting is 24 hours. Press **ENT**, wait until “>” appears, the modification can be made.

YY- MM- DD HH:MM:SS
03- 04- 04 10:05:04

Menu **6** **1**

ESN

Display electronic serial number (ESN) of the instrument. This ESN is the only one assigned to each Flowmeter ready to leave the factory. The factory uses it for files setup and the user uses it for management.

Ultrasonic Flowmeter
S/N=05071188

Menu **6** **2**

Serial Port Settings

This window is used for serial port setting. Serial port is used to communicate with other instruments.

The serial port parameters setting of the instrument that applies the serial port connection must be consistence. The first selected data indicates baud rate, 9600, 19200, 38400, 56000, 57600, 115200 are available.

The second option indicates parity bit, None (No verification).

Data length fixed to 8;

Stop bit length for a fixed length.

The factory default serial port parameter is “9600, None”

RS- 232 Setup [62
9600, None

Menu **6** **3**

AI1 Analog Input Value Range

This window is for entering Analog Input 4mA and 20mA for temperature or pressure value.

AI 1 Value Range [63
10 - 100

Menu **6** **4**

AI2 Analog Input Value Range

This window is for entering Analog Input 4mA and 20mA for temperature or pressure value.

AI 2 Value Range [64
10 - 100

Menu **6** **7**

Set FO Frequency Range

Set up high FO frequency range. It must be higher than the low FO frequency. Ranges from 1-9999Hz. Factory default is 1~1001 Hz.

Note: The frequency output is transmitted through OCT Serial Port; therefore the OCT must be set to the frequency output mode.

FO Frequency Range
1 - 5000

Menu **6** **8**

Low FO Flow Rate

Set up low FO flow rate, i.e. the corresponding flow value when output signal frequency is at the lowest FO frequency. For example, when the low FO frequency is 1000Hz, low FO flow rate is 100m3/h then when the frequency output is 1000Hz, the low flow at this moment measured by the Flowmeter is 100m3/h.

Low FO Flow Rate [68
0 m3/h

Menu **6** **9**

High FO Flow Rate

Enter the high FO flow rate, i.e. the corresponding flow value when frequency output signal is at highest FO frequency. For example, when the low FO frequency is 3000Hz, low FO flow rate is 1000m3/h then when the frequency output is 3000Hz, the low flow at this moment measured by the Flowmeter is 1000m3/h.

High FO Flow Rate [69
26550 m3/h

Menu **7** **0**

LCD Backlit Option

Select LCD backlit controls.

0. Always OFF,
1. Always ON,
2. Lighting For nn sec

LCD Backlit Option
0. Always ON

Keep the backlight off can save about 30mA power

Menu **7** **2**

Working Timer

Display the totaled working hours of the Flowmeter since last reset. It is displayed by HH:MM:SS. If it is necessary to reset it, press **ENT**, and select "YES".

Working Timer [72
00000011:16:38

Menu **7** **7**

Beeper Setup

Set up the beeper on-off state.

- 0. ON Beeper ON
- 1. OFF Beeper OFF

BEEPER Setup [77
0. ON

Menu **8** **2**

Date Totalizer

In this window, it is possible to review the historical flow data totalizer for any day of the last 64 days, any month of the last 64 months and any year of the last 5 years.

Press **ENT**, use the **▲/+** or **▼/-** to review totalizer in days, months and years. "0" for day, "1" for month, "2" for year.

Use the **▲/+** or **▼/-** to review the totalizer in some day, some month, some year.

For example, to display the flow total for July 18,2000, the display "-----" at the upper right corner of the screen indicates that it was working properly the whole day. On the contrary, if "G" is displayed, it indicates that the instrument gain was adjusted at least once. Probably it was offline once on that day. If "H" is displayed, it indicates that poor signal was detected at least once. Also, it indicates that the operation was interrupted or problems occurred in the installation.

For more information please refer to "Error Code and Resolutions".

Menu **8** **3**

Automatic Flow Correction

With the function of automatic flow correction, the flow lost in an offline session can be estimated and automatically adjusted. The estimate is based on the average value, which is obtained from flow rate before going offline and flow measured after going online the next time, multiplied times the time period that the meter was offline. Select "ON" to use this function and "OFF" to cancel this function.

Date Totalizer [82
0. Day

00 03- 04- 05 G- H- I
- 0 m3

00 03- 04- 05 - - - - -
>4356.78 m3

Automatic Correction
YES

Menu **9** **0**

Signal Strength and Signal Quality

Display the measured signal strength and signal quality Q value upstream and downstream.

Signal strength is indicated from 00.0~99.9. A

Strength+Quality [90
UP:00.0 DN:00.0 Q=00

reading of 00.0 indicates no signal detected, while 99.9 indicates maximum signal strength. Normally the signal strength should be ≥ 60.0 . Signal quality Q is indicated by 00 ~ 99. Therefore, 00 indicates the poorest signal while 99 indicates the best signal. Normally, signal quality Q value should be better than 50.

During the installation, pay attention to the signal strength and signal quality, the higher, the better. The strong signal strength and high quality value can ensure the long-term stability and the high accuracy of the measurement results.

Menu 9 1

TOM/TOS*100

Display the ratio between the actual measured transmit time and the calculated transmit time according to customer's requirement. Normally the ratio should be $100 \pm 3\%$. If the difference is too large, the user should check whether the parameters are entered correctly, especially the sound velocity of the fluid and the installation of the transducers. This data is of no use before the system is ready.

TOM/TOS* 100 [91
0.0000%

Menu 9 2

Fluid Sound Velocity

Display the measured fluid sound velocity. Normally this value should be approximately equal to the entered value in Window M21. If the difference is too large, it probably results from an incorrect value entered in Window M21 or improper installation of the transducers.

Fluid Sound Velocity
1443.4 m/s

Menu 9 3

Total Time and Delta Time

Display the measured ultrasonic average time (unit: μS) and delta time of the upstream and downstream (unit: nS) time. The velocity calculation in the Flowmeter is based on the two readings. The delta time is the best indication that the instrument is running steadily. Normally the fluctuation in the ratio of the delta time should be lower than 20%. If it is not, it is necessary to check if the transducers are installed properly or if the parameters have been entered correctly.

Totl Time, Delta Time
8.9149 μS , - 171.09 nS

Menu 9 4

Reynolds Number and Factor

Display the Reynolds number that is calculated by the Flowmeter and the factor that is set currently by the Flowmeter. Normally this scaling factor is the average

Reynolds Number [94
0.0000 1.0000

of the line and surface velocity factor inside the pipe.

Menu ▲/+ 0

Power ON/OFF Time

To view the power on/off time and flow rate for the last 64 update times to obtain the offline time period and the corresponding flow rate. Enter the window, press **ENT** and **▲/+** to display the last update before the last 64 times of on/off time and flow rate values. “ON” on right hand indicates that time power is on; “00” on the upper left corner indicates “00-07-18 12:40:12” the date time; flow rate is displayed in the lower right corner.

00- 07 18 12:40:12
* ON 123.65 m3/h

ON/OFF Time [+0
Press ENT When Ready

Menu ▲/+ 1

Total Working Hours

With this function, it is possible to view the total working hours since the Flowmeter left the factory. The figure on the right indicates that the total working hours since the Flowmeter left the factory is 1107 hours 1 minutes 41 seconds.

Total Wbr k Hours [+1
00001107:01:41

Menu ▲/+ 2

Last Power Off Time

Display the last power off time.

Last Power Of f Time
03- 04- 04 11:33:02

Menu ▲/+ 3

Last Flow Rate

Displays the last flow rate.

Last Flow Rate [+3
100.43 m3/h

Menu ▲/+ 4

Total ON/OFF Times

Display total on/off times since the Flowmeter left the factory.

ON/OFF Times [+4
40

Menu ▼/- 0

Analog Output Verification

Please refer to the 5.5 “4~20mA Analog Output Verification (Optional)”

Har dware Adjusting
Entry

7. Error Diagnoses

The ultrasonic Flowmeter has advanced self-diagnostics functions and displays any errors in the upper right corner of the LCD via definite codes in a date/time order. Hardware error diagnostics are usually performed upon each power on. Some errors can be detected during normal operation. Undetectable errors caused by incorrect settings and unsuitable measurement conditions can be displayed accordingly. This function helps to detect the errors and determine causes quickly; thus, problems can be solved in a timely manner according to the solutions listed in the following tables.

Errors displayed in the Flowmeter are divided into two categories:

Table 1 is for errors displayed during self-diagnostics upon power on. “* F” may be displayed on the upper left corner of the screen after entering the measuring mode. When this occurs, it is necessary to power on for self-diagnostics once again to detect and solve possible errors using the table below. If a problem still exists, please contact the factory or the factory’s local representative for assistance.

Table 2 applies when errors caused by incorrect settings and signals are detected and are announced by error codes displayed in Window M08.

7.1 Table 1. Self-diagnoses and error solutions (upon power on)

| LCD Display | Cause | Solution |
|---|--------------------------------------|---|
| Rom Parity Error | System ROM illegal or error | Contact the factory |
| Stored Data Error | System stored data block error | Power on again or contact the factory |
| SCPU Fatal Error | SCPU circuit fatal error | Power on again or contact the factory |
| Timer DCTow Error Timer Fast Error | System clock error | Contact the factory |
| CPU or IRQ Error | CPU or IRQ problem | Power on again |
| System RAM Error | System RAM questionable | Power on again or contact the factory |
| Time or Bat Error | System date time chip error | Power on again or contact the factory |
| No Display, Erratic or Abnormal Operation | Bad wiring connection | Check wiring connections |
| Stroke Key - No Response | Keypad locked or bad plug connection | Enter the unlock password if the keypad is locked |

7.2 Table 2. Error codes and solutions (during operation)

| Code | M08 Display | Cause | Solution |
|------|--|--|---|
| *R | System Normal | System normal | No errors |
| *J | SCPU Fatal Error | Hardware defect | Contact the factory |
| *I | Signal Not Detected | Signal not detected. | Attach transducer to the pipe and tighten it securely. Apply a plenty of coupling compound on transducer and pipe wall. |
| | | Spacing is not correct between the transducers or not enough coupling compound applied to face of transducers. | Remove any rust, scale, or loose paint from the pipe surface. Clean it with a file. |
| | | Transducers installed improperly. | Check the initial parameter settings. |
| | | Scale is too thick. | Remove the scale or change the scaled pipe section. Normally, it is possible to change a measurement location. The instrument may run properly at a new site with less scale. |
| | | New pipe liner. | Wait until liners solidified and saturated. |
| *H | Low Signal Strength | Low signal strength. Cause refers to above-mentioned reasons. | Solution refers to above-mentioned solutions. |
| *H | Poor Signal Quality | Poor signal quality All reasons are included in the above-mentioned causes. | Solution refers to above-mentioned solutions. |
| *F | Refer to Table 1. | Error in self-diagnoses during power on. | Power on again; resolve it by the method listed in Table 1. If it is still a problem, contact the factory. |
| | | Permanent hardware error. | Contact the factory. |
| *G | Adjusting Gain>S1 Adjusting Gain>S2 Adjusting Gain>S3 Adjusting Gain>S4 (Display in Windows M00,M01,M02,M03) | Adjusting gain for normal measurement. Stop in S1 or S2 and only switch between S1 and S2 indicates a poor waveform or low signal strength. All reasons may be included in above-mentioned items. | |
| *K | Pipe Empty. Set in Window M29 | No fluid in pipe or settings incorrect. | Once fluid is detected in the pipe, set 0 in Window M29. |

7.3 Frequently Asked Questions and Answers

Question: New pipe, high quality material, and all installation requirements met: why still no signal detected?

Answer: Check pipe parameter settings, installation method and wiring connections. Confirm if the coupling compound is applied adequately, the pipe is full of liquid, transducer spacing agrees with the screen readings and the transducers are installed in the right direction.

Question: Old pipe with heavy scale inside, no signal or poor signal detected: how can it be resolved?

Answer: Check if the pipe is full of fluid. Try the Z method for transducer installation (If the pipe is too close to a wall, or it is necessary to install the transducers on a vertical or inclined pipe with flow upwards instead of on a horizontal pipe).

Carefully select a good pipe section and fully clean it, apply a wide band of coupling compound on each transducer face (bottom) and install the transducer properly.

DCTowly and DCTightly move each transducer with respect to each other around the installation point until the maximum signal is detected. Be careful that the new installation location is free of scale inside the pipe and that the pipe is concentric (not distorted) so that the sound waves do not bounce outside of the proposed area.

For pipe with thick scale inside or outside, try to clean the scale off, if it is accessible from the inside. (Note: Sometimes this method might not work and sound wave transmission is not possible because of the a layer of scale between the transducers and pipe inside wall).

Question: Why is the flow rate still displayed as zero while there is fluid inside the pipe and a symbol of “R” displayed on the screen?

Answer: Check to see if “Set Zero” was carried out with fluid flowing inside the pipe(Refer to Window M42). If it is confirmed, recover the factory default in Window M43
