

Selection Guide | VACON® 10 | VACON® 20 | VACON® 20 Cold Plate | 0.25 kW - 18.5 kW

Flexible and easy to use compact AC drives



FAST
set-up and
installation



Creating perfect harmony

Drives help improve the control of machines and increase energy efficiency. Selecting the right AC drive is, however, more than just selecting the right product – it is just as much about selecting a supplier with the right attitude towards partnership. Aiming for perfect harmony means selecting the right product, the optimum solution and the best co-operation... And doing it all in harmony with nature.

We very much understand, and we have seen it so many times, that our success is always a result of our customer's success. When our customer is the winner in his market, we as a partner are also a winner. Working with us you can be sure that all the efforts are made to reach the best end result – be it product related, solutions related, logistics and support related.

Our team of drives professionals is here to provide our expertise and skills in order to serve our customers in the best possible way. Our target is a long-term relationship built on confidence and trust – to us that is perfect harmony.



What is harmony?

We see harmony as a state of balance. The feeling that the solution created is the best possible for your specific needs. That the supplier selected is the right one. That there is good communication and an understanding of your needs. That environmental issues are handled in the best possible way.

A dedicated OEM supplier

Harmony in products

To meet the various needs of our customers we have created a wide range of AC drive products. All the products: VACON® 10, VACON® 20 and VACON® 20 Cold Plate have one major thing in common. They are designed to be efficient and easy to use. Applying the product should be easy, it should fit into the space available for it and we want the installation and configuration time to be as short as possible.

Harmony in customization

Machinery and products produced in large quantities should be well optimized and efficient. A standard drive solution is not always the optimum solution. We have developed our working processes in a way that allows us to customize the products to meet customer needs. So if you are a high volume user of drives, contact your local partner to find out how we can create a world-class drives solution together.

In harmony with the environment

The use of AC drives is one of the key contributors to energy saving and thus to reduced emissions and pollution. We aim to be an all around environmentally friendly company – our products are a good example of that. You can also see it in our ways of working. We have developed our manufacturing process in order to minimize the impact on the environment. All excess materials in the production and service processes are carefully sorted and recycled.





VACON® 10 – as easy as possible

The VACON® 10 is an AC drive designed for applications where simplicity and efficiency are the key requirements. When you need a compact AC drive that does its job without extra hassle, the VACON® 10 is the product you should be taking a closer look at.

The leading design feature of the VACON® 10 is simplicity, which means short handling time. It has all the functionality built into one simple unit. Our VACON® 10 customers appreciate a quick setup and compact size.

Fast installation

Choose VACON® 10, and benefit from the quick installation process. If the drive is mounted on a DIN rail no screws are required for the fixing. No external components, such as RFI filters etc., are needed as they can all be integrated into the drive.

Fast setup

In order to save our customers time, we have created tools to program the VACON® 10 as efficiently as possible.

A start-up wizard in the drive allows for programming with as few as three parameters. With the MCA Unit, our customers can clone their drive in seconds – all without connecting main power to the drive.

Compact size

The space available for the drive is often limited. It is also a cost factor as providing more space leads to increased cost for the enclosure. The secret behind the compact size of the VACON® 10 is the unique cooling concept of the drive. It is made just like most PC computers – a high efficiency forced cooled heat sink mounted directly onto the power semiconductors.

Key benefits:

- Short installation time
- Space saving design
- Parameter copying without main power

Typical applications:

- Pumps
- Fans
- Conveyors

Technical highlights:

- Easy to use push button interface
- Wide standard I/O
- Temperature controlled cooling fan
- Side by side mounting
- EMC filter built-in
- PI controller built-in



Ratings and dimensions

Supply voltage	AC drive type	Power		Motor current		Enclosure size	Dimensions W x H x D		Weight	
		kW	HP	I _N [A]	1.5 x I _N [A]		mm	inches	kg	lb
105-120 VAC, 1-phase (North America only)	VACON0010-1L-0001-1	0.25	0.33	1.7	2.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0010-1L-0002-1	0.37	0.5	2.4	3.6					
	VACON0010-1L-0003-1	0.55	0.75	2.8	4.2					
	VACON0010-1L-0004-1	0.75	1	3.7	5.6	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0010-1L-0005-1	1.1	1.5	4.8	7.2					
208-240 VAC, 1-phase	VACON0010-1L-0001-2	0.25	0.33	1.7	2.6	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0010-1L-0002-2	0.37	0.5	2.4	3.6					
	VACON0010-1L-0003-2	0.55	0.75	2.8	4.2					
	VACON0010-1L-0004-2	0.75	1	3.7	5.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0010-1L-0005-2	1.1	1.5	4.8	7.2					
	VACON0010-1L-0007-2	1.5	2	7	10.5	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0010-1L-0009-2	2.2	3	9.6	14.4					
208-240 VAC, 3-phase	VACON0010-3L-0001-2	0.25	0.33	1.7	2.6	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0010-3L-0002-2	0.37	0.5	2.4	3.6					
	VACON0010-3L-0003-2	0.55	0.75	2.8	4.2					
	VACON0010-3L-0004-2	0.75	1	3.7	5.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0010-3L-0005-2	1.1	1.5	4.8	7.2					
	VACON0010-3L-0007-2	1.5	2	7	10.5	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0010-3L-0011-2	2.2	3	11	16.5					
380-480 VAC, 3-phase	VACON0010-3L-0001-4	0.37	0.5	1.3	2.0	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0010-3L-0002-4	0.55	0.75	1.9	2.9					
	VACON0010-3L-0003-4	0.75	1	2.4	3.6					
	VACON0010-3L-0004-4	1.1	1.5	3.3	5.0	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0010-3L-0005-4	1.5	2	4.3	6.5					
	VACON0010-3L-0006-4	2.2	3	5.6	8.4	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0010-3L-0008-4	3	4	7.6	11.4					
	VACON0010-3L-0009-4	4	5	9	13.5					
VACON0010-3L-0012-4	5.5	7.5	12	18.0						
520-600 VAC, 3-phase (North America only)	VACON0010-3L-0002-7	0.75	1	1.7	2.6	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0010-3L-0003-7	1.5	2	2.7	4.1					
	VACON0010-3L-0004-7	2.2	3	3.9	5.9					
	VACON0010-3L-0006-7	4	5	6.1	9.2					
	VACON0010-3L-0009-7	5.5	7.5	9	13.5					



VACON® 20 – possibilities and performance

The VACON® 20 AC drive comes packed with functionality and possibilities to bring any machine control to a completely new level. The compact size in combination with a wide power range is the base, but the VACON® 20's possibilities do not end there. A built-in PLC functionality, which is one of the most flexible on the market, makes this product adapt to every task and bring cost savings to the user.

In order for machine builders to be able to compete in an increasingly competitive market, it is important to continuously seek solutions to further improve performance and cost efficiency – VACON® 20 offers new possibilities here.

Wide power range

The VACON® 20 is available in all common voltages in the range of 105-600 V. Combined with a wide power range up to 18.5 kW /25 HP. The VACON® 20 has something for customers all over the globe. Customers can reduce costs by implementing our harmonized product range and increase efficiency in their manufacturing processes. In currents above 16A the drive is available with a built-in harmonic filtering choke for public networks according to IEC61000-3-12.

Cutting-edge performance

Machinery performance is very much dependent on the performance of the AC drive. In the VACON® 20 we have done our best to cut cycle times and maximize the control performance of the drive. The built-in RS485 interface offers a cost effective and simple serial control interface for the drive. With

optional modules, the VACON® 20 can be connected to almost any fieldbus system including CANOpen, DeviceNet and PROFIBUS DP.

Fast installation and set-up

The VACON® 20 is designed for efficient volume manufacturing where every second in installation and configuration time counts. Easy access terminals, built-in DIN rail mounting and the MCA parameter copying tool which can clone settings without main power in the drive are all examples of features that help reduce start-up time.

Built-in PLC functionality based on IEC61131-3

The built-in PLC functionality presents an opportunity to increase machine performance and save costs. The customer can build his own control logic in the drive and utilize unused I/O of the drive for performing other machine related tasks. Another unique feature of the VACON® 20 is that the parameter list can be freely modified and application specific parameter sets and default settings can be created. By utilizing the opportunities of optimizing the drive control VACON® 20 can help make better and more cost efficient machine designs.

Key benefits:

- Fieldbus connectivity
- Parameter copying without main power
- Custom-made software possible

Typical applications:

- Pumps and fans
- Conveyors
- Packaging, processing and washing machines

Technical highlights:

- Wide power range up to 18.5 kW
- High performance and functionality
- Full I/O + option board support
- Fast installation and setup
- Built-in choke as option in $\geq 16A$ types
- Induction and permanent magnet (PM) motor support



Ratings and dimensions

Supply voltage	AC drive type	Power		Motor current		Enclosure size	Dimensions W x H x D		Weight	
		kW	HP	I _N [A]	1.5 x I _N [A]		mm	inches	kg	lb
105-120 VAC, 1-phase (North America only)	VACON0020-1L-0001-1	0.25	0.33	1.7	2.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0020-1L-0002-1	0.37	0.5	2.4	3.6					
	VACON0020-1L-0003-1	0.55	0.75	2.8	4.2					
	VACON0020-1L-0004-1	0.75	1	3.7	5.6					
	VACON0020-1L-0005-1	1.1	1.5	4.8	7.2	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
208-240 VAC, 1-phase	VACON0020-1L-0001-2	0.25	0.33	1.7	2.6	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0020-1L-0002-2	0.37	0.5	2.4	3.6					
	VACON0020-1L-0003-2	0.55	0.75	2.8	4.2					
	VACON0020-1L-0004-2	0.75	1	3.7	5.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0020-1L-0005-2	1.1	1.5	4.8	7.2					
	VACON0020-1L-0007-2	1.5	2	7	10.5					
	VACON0020-1L-0009-2	2.2	3	9.6	14.4					
208-240 VAC, 3-phase	VACON0020-3L-0001-2	0.25	0.33	1.7	2.6	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0020-3L-0002-2	0.37	0.5	2.4	3.6					
	VACON0020-3L-0003-2	0.55	0.75	2.8	4.2					
	VACON0020-3L-0004-2	0.75	1	3.7	5.6	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0020-3L-0005-2	1.1	1.5	4.8	7.2					
	VACON0020-3L-0007-2	1.5	2	7	10.5					
	VACON0020-3L-0011-2	2.2	3	11	16.5					
	VACON0020-3L-0012-2	3	4	12.5	18.8	MI4	165 x 370 x 165	6.5 x 14.6 x 6.5	8	18
	VACON0020-3L-0017-2	4	5	17.5	26.3					
	VACON0020-3L-0025-2	5.5	7.5	25	37.5					
	VACON0020-3L-0031-2	7.5	10	31	46.5	MI5	165 x 414 x 202	6.5 x 16.3 x 8	10	22
VACON0020-3L-0038-2	11	15	38	57						
380-480 VAC, 3-phase	VACON0020-3L-0001-4	0.37	0.5	1.3	2.0	MI1	66 x 160 x 99	2.60 x 6.30 x 3.90	0.55	1.21
	VACON0020-3L-0002-4	0.55	0.75	1.9	2.9					
	VACON0020-3L-0003-4	0.75	1	2.4	3.6					
	VACON0020-3L-0004-4	1.1	1.5	3.3	5.0	MI2	90 x 195 x 102	3.54 x 7.68 x 4.02	0.7	1.54
	VACON0020-3L-0005-4	1.5	2	4.3	6.5					
	VACON0020-3L-0006-4	2.2	3	5.6	8.4					
	VACON0020-3L-0008-4	3	4	7.6	11.4					
	VACON0020-3L-0009-4	4	5	9	13.5	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0020-3L-0012-4	5.5	7.5	12	18.0					
	VACON0020-3L-0016-4	7.5	10	16	24					
	VACON0020-3L-0023-4	11	15	23	34.5	MI4	165 x 370 x 165	6.5 x 14.6 x 6.5	8	18
	VACON0020-3L-0031-4	15	20	31	46.5					
	VACON0020-3L-0038-4	18.5	25	38	57	MI5	165 x 414 x 202	6.5 x 16.3 x 8	10	22
520-600 VAC, 3-phase (North America only)	VACON0020-3L-0002-7	0.75	1	1.7	2.6	MI3	100 x 255 x 109	3.94 x 10.04 x 4.29	0.99	2.18
	VACON0020-3L-0003-7	1.5	2	2.7	4.1					
	VACON0020-3L-0004-7	2.2	3	3.9	5.9					
	VACON0020-3L-0006-7	4	5	6.1	9.2					
	VACON0020-3L-0009-7	5.5	7.5	9	13.5					



VACON® 20 Cold Plate – flexibility in cooling

When the environment is more demanding or there is a cooling media such as liquid already available, the AC drive cooling can also be optimized further. The VACON® 20 Cold Plate shares the control and power topology with the standard VACON® 20 drive, but offers completely new possibilities for creating unique and efficient cooling solutions.

AC drives are extremely energy efficient products; they do however, still generate some heat. The heat loss can sometimes limit the density of the machine design, especially if mounted in a sealed enclosure simply because there is no air circulation. The VACON® 20 Cold Plate design is based around a flat surface of the drive onto which the majority of the heat losses are concentrated. By attaching this surface to a cooling element, i.e. to the “cold plate”, the cooling of the drive can work even under the most demanding circumstances.

Use any cooling media

As the cooling is done through a clear cooling interface, it is possible to use different cooling media depending on the situation. By attaching the drive to a heat sink with large cooling ribs, a fully passively cooled drive is created. As an alternative, the drive can be mounted on a plate, which is cooled by liquid in order to create a liquid cooled drive solution. Other possible cooling media include different types of refrigerants or metal constructions with a high heat energy conducting mass.

Compact sealed enclosures

If the heat transport from the drive is not handled through air circulation, but through the heat being conducted out of the enclosure through a flat metal surface, the sealing of the enclosure is no longer a factor that significantly affects the cooling performance. It is thus possible to create and install the drive enclosure in environments with high amounts of dust and moisture. The VACON® 20 has a unique form that is designed to allow slim and flat enclosure solutions that can be highly integrated in the machine construction to be created.

Built-in PLC functionality according to IEC61131-3

The VACON® 20 Cold Plate utilizes the advanced control concept of the VACON® 20 product family, offering full control performance and functionality. It also supports the built-in PLC functionality that allows the creation of application-specific software and solutions.

Key benefits:

- Highest cooling flexibility
- Fast plugging of I/O wiring
- Custom-made software possible

Typical applications:

- Textile machinery
- Hoists and cranes
- Conveyors in demanding environment
- Compressors and heat pumps

Technical highlights:

- Cold plate cooling
- Unique low depth design
- STO – Safe Torque Off according to SIL2
- High performance and functionality
- High ambient temperature rating up to 70 °C
- Induction and permanent magnet (PM) motor
- Integrated brake resistor
- Status LED lights on drive
- Expansion slot for I/O or fieldbus
- Handheld text keypad with copy function
- Single plug I/O connector for OEMs



Ratings and dimensions

Supply voltage	AC drive type	Power		Motor current		Enclosure size	Dimensions W x H x D		Weight	
		kW	HP	I_N [A]	$1.5 \times I_N$ [A]		mm	inches	kg	lb
380-480 VAC, 3-phase	VACON0020-3L-0003-4-CP	0.75	1	2.4	3.6	MS2	133 x 159 x 80	5.24 x 6.26 x 3.15	2	4.4
	VACON0020-3L-0004-4-CP	1.1	1.5	3.3	5.0					
	VACON0020-3L-0005-4-CP	1.5	2	4.3	6.5					
	VACON0020-3L-0006-4-CP	2.2	3	5.6	8.4					
	VACON0020-3L-0008-4-CP	3.0	5	7.6	11.4	MS3	161 x 240 x 83	6.34 x 9.45 x 3.27	3	6.6
	VACON0020-3L-0009-4-CP	4.0	6	9.0	13.5					
	VACON0020-3L-0012-4-CP	5.5	7.5	12.0	18.0					
	VACON0020-3L-0016-4-CP	7.5	10	16.0	24.0					
208-240 VAC, 3-phase	VACON0020-3L-0004-2-CP	0.75	1	3.7	5.6	MS2	133 x 159 x 80	5.24 x 6.26 x 3.15	2	4.4
	VACON0020-3L-0005-2-CP	1.1	1.5	4.8	7.2					
	VACON0020-3L-0007-2-CP	1.5	2	7	10.5					
	VACON0020-3L-0011-2-CP	2.2	3	11	16.5	MS3	161 x 240 x 83	6.34 x 9.45 x 3.27	3	6.6
	VACON0020-3L-0012-2-CP	3	4	12	18.0					
	VACON0020-3L-0017-2-CP	4	5	17.5	26.3					

Tailoring the software

VACON® Programming

The VACON® 20 product's built-in PLC functionality and programming is in accordance with IEC61131-3. The optional tool enables the user to modify the drive software by editing the existing application logic or by creating completely new software. The parameter list and default settings are edited with a separate tool.

PC interface and parameter copying

The MCA (Micro Communications Adapter) is a snap-on and intelligent copying unit for VACON® 10 and VACON® 20 products.

- Parameter copying without main power in the drive
- Download settings directly to the MCA from PC without a drive
- HW interface for PC connection to the drive

The VACON® 20 Cold Plate drive parameter copying is done with the handheld keypad.



MCA adapter

I/O Configuration

Terminal	Description	VACON® 10	VACON® 20	VACON® 20 CP
1	+10 V _{ref}	Maximum load 10 mA	■	■
2	AI1	0-10V	■	■
3	GND		■	■
4	AI2	0-10V / 0(4)-20mA*	0(4)-20mA	■
5	GND		■	■
6	24 V _{out}	Max. 50 mA / CP 100 mA	■	■
7	GND/DIC*		GND	■
8	DI1	0-+30 V R _i = 12 kΩ Cold Plate R _i = 4 kΩ	■	■
9	DI2		■	■
10	DI3		■	■
13	DOC	Digital output common	GND	■
14	DI4	0-+30 V R _i = 12 kΩ Cold Plate R _i = 4 kΩ	■	■
15	DI5		■	■
16	DI6		■	■
18	AO	Analogue output	0(4)-20mA	0-10V / 0(4)-20mA*
20	DO	Open collector, max. load 48 V/50 mA	■	■
22	RO 13 - CM	Relay output 1	■	■
23	RO 14 - NO		■	■
24	RO 22 - NC	Relay output 2	■	■
25	RO 21 - CM		■	■
26	RO 24 - NO		■	■
A	A - RS485	Modbus RTU	■	■
B	B - RS485	Modbus RTU	■	■
	STO	Inputs S1, G1, S2, G2 Feedback F+/F-		■

* Selectable



Option board mounting kit



Keypad door mounting kit

Type code key

VACON 0020 - 3L - 0009 - 4 - CP + OPTION CODES



IP21/NEMA1 kit

Technical data

Mains connection	Input voltage U_{in}	105...120 V, -15 %...+10 % 1-phase 208...240 V, -15 %...+10 % 1-phase 208...240 V, -15 %...+10 % 3-phase 380...480 V, -15 %...+10 % 3-phase 520...600 V, -15 %...+10 % 3-phase
	Input frequency	45...66 Hz
	Connection to mains	Once per minute or less (normal case)
Motor connection	Output voltage	0... U_{in} (2 x U_{in} with 105...120 V drives)
	Output current	Continuous rated current I_N at rated ambient temperature overload 1.5 x I_N max. 1 min/10 min
	Starting current / Torque	Current 2 x I_N for 2 secs in every 20 sec period Torque depends on motor
	Output frequency	0...320 Hz
	Frequency resolution	0.01 Hz
Control characteristics	Control method	Frequency control U/f. Open loop sensorless vector control
	Switching frequency	1.5...16 kHz; Factory default 4 kHz, (520...600 V model default 2 kHz) Cold Plate models 6 kHz
	Braking torque	100 % x T_N with brake chopper in 3-phase version sizes MS2-3, MI2-5 30 % x T_N with DC-braking. Dynamic flux braking available in all types
Ambient conditions	Ambient operating temperature	-10 °C (no frost)...+50 °C: rated loadability I_N (1L-0009-2, 3L-0007-2, 3L-0011-2 and with options ENC-IP21-Mlx and ENC-IN01-Mlx ambient max +40 °C) Cold Plate models -10 °C...+70 °C
	Storage temperature	-40 °C...+70 °C
	Altitude	100 % load capacity (no derating) up to 1000 m 1 % derating for each 100 m above 1000 m; max. 2000 m Cold Plate max 3000 m
	Enclosure class	MI1-3: IP20, MI4-5: IP21, Cold Plate: IP00
EMC	Immunity	Complies with EN61800-3 (2004)
	Emissions	208-240 V: EMC level C2: with an internal +EMC2 option 380-480 V: EMC level C2: with an internal +EMC2 option
Approvals	EN61800, C-Tick, Gost R, CB, CE, UL, cUL, KC (not all versions, see unit nameplate for more detailed approvals)	

Factory installed options code	Description	Suitability		
		VACON® 10	VACON® 20	VACON® 20 CP
+EMC2	C2-Level EMC filter (includes +QPES)	■	■	■
+QPES	Cable shield grounding kit	■	■	
+QFLG	Flange mounting kit for MI4 and MI5		■	
+DBIR	Integrated cold plate brake resistor			■
+LS60	60 Hz defaults on motor control	■	■	■
Application software				
=+A1051	VACON® 20 PFC Application		■	■
=+A1053	VACON® 10 PFC Application	■		

Separately delivered options code	Description	Suitability		
		VACON® 10	VACON® 20	VACON® 20 CP
ENC-SLOT-MC03-13	Option board mounting kit VACON® 20 MI1-MI3		■	
ENC-SLOT-MC03-45	Option board mounting kit VACON® 20 MI4-MI5		■	
ENC-IP21-Mlx	IP21 cover MI1-MI3. x=1,2,3	■	■	
ENC-IN01-Mlx	NEMA 1 Kit MI1-MI5. x=1,2,3,4,5	■	■	
ENC-QPES-Mlx	PE kit MI1-MI5. x=1,2,3,4,5	■	■	
VACON-ADP-MCAA	MCA RS422 adapter w/ parameter copy	■	■	
CAB-USB/RS-485	USB to RS485 cable for PC			■
VACON-ADP-MCAA-KIT	Kit with VACON-ADP-MCAA and CAB-USB/RS485	■	■	
VACON-ADP-PASSIVE	Passive RS422 adapter		■	
VACON-PAN-HMDR-TMX-MC03	VACON® 20 door mounting kit with text keypad and VACON-ADP-PASSIVE		■	
CAB-RJ45P-2M	2m RJ45 cable for door mounting kit		■	
CAB-RJ45P-3M	3m RJ45 cable for door mounting kit		■	
CAB-RJ45P-6M	6m RJ45 cable for door mounting kit		■	
CAB-RJ45P-15M	15m RJ45 cable for door mounting kit		■	
VACON-PAN-HMDR-TMX-MC03-2M	VACON® 20 door mounting kit with VACON-PAN-HMDR-TMX-MC03 and CAB-RJ45P-2M		■	
VACON-PAN-HMDR-TMX-MC03-3M	VACON® 20 door mounting kit with VACON-PAN-HMDR-TMX-MC03 and CAB-RJ45P-3M		■	
VACON-PAN-HMDR-TMX-MC03-6M	VACON® 20 door mounting kit with VACON-PAN-HMDR-TMX-MC03 and CAB-RJ45P-6M		■	
VACON-PAN-HMDR-TMX-MC03-15M	VACON® 20 door mounting kit with VACON-PAN-HMDR-TMX-MC03 and CAB-RJ45P-15M		■	
CAB-HMI2M-MC05-X	MC05 IP66 HMI cable l=2m for -X keypads option			■
CAB-HMI5M-MC05-X	MC05 IP66 HMI cable l=5m for -X keypads option			■
VACON-PAN-HMDR-MC03	Complete IP54 keypad door kit+3m cable+adapater		■	■
VACON-PAN-HMTX-MC06-CP	Handheld/magnetic fixing IP66 text keypad w/ cable, l=1m/39,37 inches		■	■
PAN-HMWM-MK02	Keypad wall-mounting kit		■	■
Option boards (all boards are varnished)				
OPT-B1-V	6 x DI / DO, Each digital input individually can be programmed also to be as digital output		■	■
OPT-B2-V	2 x relay output + thermistor		■	■
OPT-B4-V	1 x AI, 2 x AO (isolated)		■	■
OPT-B5-V	3 x relay output		■	■
OPT-B9-V	1xRO, 5xDI (42-240VAC)		■	■
OPT-BF-V	1 x AO, 1 x DO, 1 x RO		■	■
OPT-BH-V	3 x temperature measurement (support for PT100, PT1000, NI1000, KTY84-130, KTY84-150, KTY84-131)		■	■
OPT-C4-V	Lonworks		■	■
OPT-E3-V	PROFIBUS DPV1		■	■
OPT-E5-V	PROFIBUS DPV1 (D9)		■	■
OPT-E6-V	CANopen		■	■
OPT-E7-V	DeviceNet		■	■
OPT-EC-V	EtherCAT		■	■



Danfoss Drives

Danfoss Drives is a world leader in variable speed control of electric motors. We aim to prove to you that a better tomorrow is driven by drives. It is as simple and as ambitious as that.

We offer you unparalleled competitive edge through quality, application-optimized products targeting your needs – and a comprehensive range of product lifecycle services.

You can rely on us to share your goals. Striving for the best possible performance in your applications is our focus. We achieve this by providing the innovative products and application know-how required to optimize efficiency, enhance usability, and reduce complexity.

From supplying individual drive components to planning and delivering complete drive systems; our experts are ready to support you all the way.

We draw on decades of experience within industries that include:

- Chemical
- Cranes and Hoists
- Food and Beverage
- HVAC
- Lifts and Escalators
- Marine and Offshore
- Material Handling
- Mining and Minerals
- Oil and Gas
- Packaging
- Pulp and Paper
- Refrigeration
- Water and Wastewater
- Wind

You will find it easy to do business with us. Online, and locally in more than 50 countries, our experts are never far away, reacting fast when you need them.

Since 1968, we have been pioneers in the drives business. In 2014, Vacon and Danfoss merged, forming one of the largest companies in the industry. Our AC drives can adapt to any motor technology and we supply products in a power range from 0.18 kW to 5.3 MW.

VLT® | VAGON®

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.